

# BAZOONGI KIDS®

## " Kids Cottage "

Item # 11100/#11101/#11102  
/#11108#11109/#11110

"Kids Cottage" is our latest Bazoongi Kids® Play Structure. It is made of industrial approved spun bonded material of bright and rich colours. Our innovative design allows easy assemble. The revolutionary G3 poles Add strength to the Structure. Enjoy your Play Structure and be sure to contact us for any further information.

**PLEASE READ ALL OF THE DIRECTIONS PRIOR TO ASSEMBLY. DO NOT APPLY EXCESS FORCE TO THE POLES DURING ASSEMBLY.**

### Parts List

2 - Long Blue Poles	1 - Long White Poles
2 - Short Blue Poles	4 - Short White Poles
4 - Red Poles	1 - Cottage Tent Body
2 - Yellow Poles	1 - Floor Sheet

1. Assemble the G3 Frame completely BEFORE placing the Cottage Tent Body on the frame.
2. Assemble all of the segments of the shock corded G3 poles.
3. Using the 2 long Blue Poles and the 2 Short Blue Poles, Press the poles into the corner fitting to make a rectangular base.(Fig.A)
4. Press the 4 Red Poles into the Upright slots of the corner connectors on the rectangular Base.(Fig.B)
5. Attach the Yellow Poles to the top of the Red Poles.(Fig.C)
6. Insert the 4 Short White Poles into the Receptacles on the Yellow Poles.(Fig.D)
7. Attach the Long White Poles to the 4 Short White Poles using the attached connectors.(Fig.E)
8. Slide the material of Cottage Tent OVER the assembled frame.
9. Flip Cottage Tent on it's side and the slide the bottom corners of the frame into the pockets on the tent body.
10. Attach the floor sheet below the Cottage Tent by Velcro sewn on the sheet.

